


6LE004021A






Vector

- (DE) Montageanleitung
- (FR) Notice d'instructions
- (GB) Mounting instructions
- (NL) Montage instructie
- (DK) Monteringsvejledning
- (FI) Asennusohje
- (NO) Montasjeanvisning
- (SE) Monterings instruktioner
- (IT) Istruzioni di montaggio
- (ES) Instrucciones de montaje
- (PT) Instruções de montagem
- (CZ) Montážní návod
- (BA) Uputstvo za montažu

- (HR) Upute za montažu
- (HU) Szerelési útmutató
- (LT) Montavimo instrukcija
- (LV) Montāžas instrukcija
- (PL) Instrukcja montażowa
- (RO) Instrucțiuni de montare
- (SK) Návod na montáž
- (RU) Инструкция по монтажу
- (BG) Инструкции за монтаж
- (GR) Οδηγίες χώνευσης
- (SI) Navodilo za montažo
- (EE) Paigaldusjuhised
- (IS) Leiðbeiningar
- (AR) دليل التركيب

ERC

EN 60670-24 (PD)



	VE103	VE106	VE110	VE112	VE212	VE312	VE412	VE118	VE218	VE318
	1	1	1	1	1	1	1	1	1	1
	2	3	3	8	8	8	8	8	8	8
				2	2	2	2	2	2	2
	1	1	1	1	2	3	4	1	2	3
	1	1	1	1	2	3	4	1	2	3
				1	1	1	1	1	1	1

