# EVERYTHING HAS CHANGED.



**ALMOST.** 

MP One® is here, the one and only two-component silicone gel in one single bottle.



## MIXAPPEAL

Thanks to the TWIST&GO Technology, designed and patented by Etelec, which enables you to mix the gel directly in the bottle without using any other containers, MP One® guarantees the performance that has made Etelec gel products a great success, also offering maximum practicality and rapidity of use, even in difficult working conditions.

Etelec and MP One<sup>®</sup>, a combination of quality, research and innovation that will now change your world and your way.

Of working.







# Extremely fast reticulation, extremely reduced installation The remove the white tear-off safety ring that prevents accidental opening of the saccidental opening of the safety ring of the saccidental opening opening of the saccidental opening open

# **5**STEPS

**Five simple steps** for an innovative mixing system.

The **pre-set amount of components**, make use of **MP One**® **precise** and **error-free** with no waste for maximum use of the supplied amount.





2

integrity

capsule containing the second component, which also guarantees product

Screw the top yellow cap all the way on. Check that the blue component is released into the bottle



3

Shake the bottle for 15 seconds to obtain an even blue mixture that can be checked through the MIXING COLOR CHECK window



4

Unscrew the cap completely to open the bottle



5)

Pour the liquid into the enclosure being insulated



### **FEATURES**

- > HIGH ELECTRICAL INSULATION
- > HIGH MOISTURE PROTECTION
- > RE-ENTERABLE
- > EXTRA FAST RETICULATION: 8 MINUTES AT 23°C

the extremely rapid cross-linking enables reduced installation times.

> LOW VISCOSITY

enables effective filling of the gaps and empty spaces inside the box

- > NO EXPIRY DATE
- > COMPLIANT WITH EU DIRECTIVE 2015/863 (ROHS 3)
- > HALOGEN FREE
- > CLASSIFIED AS NON-HAZARDOUS

  pursuant to European regulation no. 1272/2008 (clp)
- > ECO-FRIENDLY
- > NON-TOXIC
- > SOLVENT-FREE
- > ODOURLESS | NON-IRRITATING

#### **FORMATS**

#### All-in-one bottle

| Att-III-one bottle    |            |                      |
|-----------------------|------------|----------------------|
| COD.                  | ARTICLE    | VOLUME               |
| MP103                 | MP One 300 | 300 ml               |
| MP106                 | MP One 600 | 600 ml               |
| MP109                 | MP One 900 | 900 ml               |
| Reticulation tir      | ne at 23°C | 8 min                |
| Operating temperature |            | from -60°C to +200°C |
| Dielectric strength   |            | 25,5 kV/mm           |



